

STEP 3

Insert the front and rear furnace wall panels.



STEP 4

After inserting the front, rear, left and right furnace wall panels, put them on the base.



STEP 5

Turn the pan support foot.



STEP 6

Plug in the firewood tray.



STEP 7

Assembly is complete.

